## SQUARE CASSETTE 110 ASSEMBLY & INSTALLATION MANUAL

## ASSEMBLY

## FABRIC WRAP (OPTIONAL) STEP 1: Wrap the fabric around a taped 10mm spline and slide into the key way as shown in the illustration. Attach additional double sided tape to the top of the extrusion as shown in the illustration. STEP 2: Securely attach fabric to double sided tape. Use spline roller tool to embed round spline and fabric in the square cassette. STEP 3: Trim any excess fabric with a scissor.




STEP 1: Slide brackets into square cassette.

Fasten in place with #6, 3/8" Screw

Note: Don't exceed 3/8" (10mm) screw length.

STEP 2: Attach end caps by aligning it with the casette and push into place.









STEP 3: Install roller shade.

Secure center of roller to square cassette using paper wrap or other means to ensure product is not damaged during shipping.






LEASE ACMEDA



Square Cassette 110 | Assembly & Installation Manual | v1.3

2023© Copyright All Rights Reserved Rollease Acmeda

## INSTALLATION



Square Cassette 110 | Assembly & Installation Manual | v1.3 2023© Copyright All Rights Reserved Rollease Acmeda



